

N300302

♠ WARNING

- •DO NOT use NKC-125MA with the angle grinder which can NOT be fitted correctly as instructed in the manual.
- •NKC-125MA is only for grinding concrete and block. DO NOT use for grinding steel or other materials.
- •NKC-125MA must be used with the Vacuum suitable for the concrete dust.
- •NKC-125MA is only for 100-125mm Diamond Grinding Cup Wheels. DO NOT use with abrasive wheels.
- •Always check NKC-125MA for damage, cracks, or deformation before use.
- •DO NOT use NKC-125MA if it is cracked, damaged or bent as this could lead to injury.
- •Be sure to wear the protective goggles, dust mask, protective foot wear, earplugs and other protective equipment when working.
- •Keep NKC-125MA away from gasoline, solvents, and paraffin.
- •Ensure the work piece is securely clamped before working.

Explanation of the pictograms.





Read the operating



eye protection



breathing protection.







SPECIFICATIONS

Model Code	NKC-125MA
Suitable Tool	Ø100~125mm (h21mm) Diamond Grinding Cup Wheel
Weight	470g (Main Unit with adaptor system)
Work material	Concrete, Block.
Suitable	Makita / BOSCH / Dewalt / Milwaukee / Metabo / HiKOKI 100-125mm class small angle grinder.
Angle Grinders	
	Some special angle grinders (ex. X-LOCK type) may not be installed. Please scan the QR code on the left to check compatibility.


OVER VIEW

[a] Main Unit / [b] Offset Plate / [c] Milwaukee Plate / [d] Wrench / [e] Lock Nut / [f] iD20 Ring / [g] Base Flange [h] Adjustment Washer (4pcs.) / [k] Joint / [m] Washer










INSTALLATION


1. Detach the Guard from the grinder.






Check the Installation Guide.








GWS18V-7 type











WEV1500-125 / WE1500-125 type

/!\ Above grinder needs its lever and related components detached.












its original position.


Place [a] Main Unit on gearcase of the Grinder.
 Some Grinders need [b] Offset Plate or [c] Milwaukee Plate preset on its gearcase.









5. Align the center of [a] Main Unit and Spindle, then push [a] Main Unit upward until it stops.



(For some Grinders, just match the shapes of the fitting area)









7. Set [g] Flange, [f] iD20 Ring and Cup Wheel into the Spindle then tighten [e] Lock Nut by Wrench.


M14 Spindle grinder needs NKCFS-125MA. (Sold Separately)









If Spindle is off center, loosen M4 Bolt x 3pcs. at back side and adjust the position of [a] Main Unit. *Re-tighten 3 screws securely after adjustment.





8. Hold [a] Main Unit and connect the Vacuum Hose into the Duct with [k] Joint.






9. Attach the Handle to the Grinder.





SURFACE GRINDING


- 1. Securely hold the Grinder and Handle.
- 2. Turn on the switch of the vacuum and Grinder.
- 3. Place [a] Main Unit on material slowly, then move the Grinder toward the grinding direction.



CORNER GRINDING

1. Detach Front Cover and Side Cover, then replace their positions.

2. Hearafter same as "SURFACE GRINDING" on the left.



Side Cover

x 2

**100~115mm Cup Wheel doesn't need the Side Cover in Corner

⊕ x 2

Front Cover

f

If the Handle comes in contact, detach the Front Cover.

Head Office in Japan **NAKAYA CO.,LTD.** 1313-92 Yanagisawa, Sanjo, Niigata, Japan



Eto Naoya Managing Director