






















































Installation Guide
























<p>Set [f/g/i] Spacer, then screw in a Grinding Cup, [q] h23 Brush is needed for some grinders.</p> <p>4 ※In the case of h31mm Grinding Cup.</p> <p>Hold the Inner Plate of [a] and tighten the Bolt with [d] Wrench securely</p> <p>Inner Plate</p> <p>Bolt</p> <p>3</p> <p>Place [a] on the gearcase of the Grinder.</p> <p>2</p> <p>Set Upper / Lower Brackets at [a] Main Unit.</p> <p>Upper Bracket</p> <p>Lower Brackets</p> <p>[a]</p> <p>1</p> <p>BOSCH</p> <p>⚠️ XLOCK model can't be fitted.</p> <p>※Based on the web information as of 2023 Mar.</p> 	<p>12</p> <p>[g]</p> <p>[q]</p> <p>23</p> <p>7</p> <p>[i]</p> <p>12</p> <p>[g]</p> <p>(Factory preset)</p> <p>13</p> <p>1</p> <p>2</p> <p>3</p> <p>4</p> <p>5</p> <p>6</p> <p>7</p> <p>8</p> <p>9</p> <p>10</p> <p>11</p> <p>12</p> <p>13</p> <p>14</p> <p>15</p> <p>16</p> <p>17</p> <p>18</p> <p>19</p> <p>20</p> <p>21</p> <p>22</p> <p>23</p> <p>24</p> <p>25</p> <p>26</p> <p>27</p> <p>28</p> <p>29</p> <p>30</p> <p>31</p> <p>32</p> <p>33</p> <p>34</p> <p>35</p> <p>36</p> <p>37</p> <p>38</p> <p>39</p> <p>40</p> <p>41</p> <p>42</p> <p>43</p> <p>44</p> <p>45</p> <p>46</p> <p>47</p> <p>48</p> <p>49</p> <p>50</p> <p>51</p> <p>52</p> <p>53</p> <p>54</p> <p>55</p> <p>56</p> <p>57</p> <p>58</p> <p>59</p> <p>60</p> <p>61</p> <p>62</p> <p>63</p> <p>64</p> <p>65</p> <p>66</p> <p>67</p> <p>68</p> <p>69</p> <p>70</p> <p>71</p> <p>72</p> <p>73</p> <p>74</p> <p>75</p> <p>76</p> <p>77</p> <p>78</p> <p>79</p> <p>80</p> <p>81</p> <p>82</p> <p>83</p> <p>84</p> <p>85</p> <p>86</p> <p>87</p> <p>88</p> <p>89</p> <p>90</p> <p>91</p> <p>92</p> <p>93</p> <p>94</p> <p>95</p> <p>96</p> <p>97</p> <p>98</p> <p>99</p> <p>100</p>	<p>1375A etc.</p> <p>type3</p>	<p>GWS13-50 / GWS18V-13 / GWS18V-45 etc.</p> <p>type4</p>
---	--	--------------------------------	---

<p>Set [f/g/i] Spacer, then screw in a Grinding Cup, [q] h23 Brush is needed for some grinders.</p> <p>4 ※In the case of h31mm Grinding Cup.</p> 				
<p>Hold the Inner Plate of [a] and tighten the Bolt with [d] Wrench securely.</p> <p>Inner Plate</p> <p>Bolt</p> <p>3</p> 				
<p>Place [a] on the gearcase of the Grinder.</p> <p>Some models ONLY.</p> <p>2</p> 				
<p>Set Upper / Lower Brackets at [a] Main Unit.</p> <p>Upper Bracket</p> <p>Lower Brackets</p> <p>[a]</p> <p>1</p> 				
<p>DeWALT</p> <p>⚠ D28115 / D28114 / D28066 / D28131 / D28065 / D28140 type can't be fitted.</p> <p>※Based on the web information as of 2023 Mar.</p> 	<p>DWE43144N / DWE4222N / DCG414B etc.</p>  <p>type1</p>	<p>DWE4120 / DWE43066N etc.</p>  <p>type2</p>	<p>DW831 etc.</p>  <p>type3</p>	<p>DCG405B / DCG415B etc.</p>  <p>type4</p>



<p>Set [f/g/i] Spacer, then screw in a Grinding Cup, [q] h23 Brush is needed for some grinders.</p> <p>4 ※In the case of h31mm Grinding Cup.</p>						
<p>Hold the Inner Plate of [a] and tighten the Bolt with [d] Wrench securely.</p> <p>Inner Plate</p> <p>Bolt</p> <p>3</p>						
<p>Place [a] on the gearcase of the Grinder.</p> <p>2</p>						
<p>Set Upper / Lower Brackets at [a] Main Unit.</p> <p>Upper Bracket</p> <p>Lower Brackets</p> <p>[a]</p> <p>1</p>						
<p>metabo</p> <p>※Based on the web information as of 2023 Mar.</p>	<p>WPB18LTXBL115 etc.</p> <p>type1</p>	<p>WP850-125 etc.</p> <p>type2</p>	<p>WP1200-125 / WEV1500-125 W750-115 etc.</p> <p>type3</p>	<p>WEV15-125 / WE17-125 W13-125 etc.</p> <p>type4</p>	<p>WPB13-125 etc.</p> <p>type5</p>	<p>WEPBA17-125 WEPBA19-125 etc.</p> <p>type6</p>

<p>Set [f/g/i] Spacer, then screw in a Grinding Cup, [q] h23 Brush is needed for some grinders.</p>  <p>4 ※In the case of h31mm Grinding Cup.</p>	 	 				
<p>Hold the Inner Plate of [a] and tighten the Bolt with [d] Wrench securely.</p>  <p>3</p>						
<p>Place [a] on the gearcase of the Grinder.</p>  <p>2</p>						
<p>Set Upper / Lower Brackets at [a] Main Unit.</p>  <p>1</p>	 <p>Sold separately Sub Plate NKC-SPMA</p>					
<p>metabo HPT</p> <p>※Based on the web information as of 2023 Mar.</p> 	<p>G18DBALQ4 / G18DSL2Q4 etc.</p>  <p>type1</p>	<p>G12VE / G12SR4 / G12SQ2 etc.</p>  <p>type2</p>	<p>3612DAQ6 / 3612DBQ6 etc.</p>  <p>type3</p>	<p>G13SC2 etc.</p>  <p>type4</p>	<p>G12SE3 / G13SE3 etc.</p>  <p>type5</p>	<p>G12BYEQ / G13BYEQ etc.</p>  <p>type6</p>

**Check the
instruction
video.**

